

PoE Watchdog
Extend Mode
Only work when Managed Mode off
Link/Act
PoE
Link/Act
Link/Act
SYS
PWR
ON
OFF
Managed Mode
1
2
3
4
5
6
7
8
9 (Uplink)
10 (Uplink)
Port 1-8:10/100Mbps(PoE)
Port 9-10:10/100/1000Mbps


RESET
DC IN