CERRADURA INTELIGENTE CON CÓDIGO

MODELO: B027

Operating Instruction

I. Unlock with fingerprint

Press the fingerprint, when the green light turns on to verify the success with a "drip" sound, represents the lock is opened and the light goes off.

If the verification with the sound of "tick" in three times, at the same time the red light shows red and then turns green, means verification fair.
Please re-verify the fingerprint if the unlock failure.

II. Unlock with password

Touch the keyboard to wake it up, the keyboard light will be on and the fingerprint light turns to green, enter 6-digit password and press # to verify, if the password is correct, the lock will be opened and the light goes off.

◦

If the verification with the sound of "drip" in three times, at the same time the fingerprint light shows red and then turns green, means verification fair.
Please re-verify the password if the unlock failure.

III. Lock Shutting

The lock will be shutting automatic 5 seconds after unlocking.

IV. Adding fingerprint and password
(The first three users are administrators; the fourth or more users are ordinary users)
1. Adding fingerprint for the first time:
Touch the keyboard to wake it up, press “1” and ”#”, the fingerprint light goes to blue and flashing, press any fingerprints, there will be a long sound "drip" and the blue light stopped flashing, start pressing the fingerprint to be recorded in 5 times. Each time when pressing fingerprint, there will be a "drip" sound, and the green light flashing one time. After 5 times pressing the fingerprint, there will be a long “drip” sound, and the green light turns on, the fingerprint light goes off, which means the operation is successful. (Press 5 different areas of one finger for lock identification in 5 times for better verification)

2.Adding password for the first time:
Touch the keyboard to wake it up, press “1” and ”#”, the fingerprint light goes to blue and flashing, press any fingerprints, there will be a long sound "drip" and the blue light stopped flashing, enter 6-digit password and press “#” to verify, there will be a "drip" sound and the green light will turn on, enter the 6-digit password again and press the "#" key to confirm. If

the entered password is same in twice, it will have same long "drip", and the green light will turn on and goes off, that means successful entering. If there are "drip" sound in three times, and the red light is on and goes off, it means that the password is inconsistent between the two input, that means unsuccessful entering. Please enter again.

3.Adding users for the second time:
Touch the keyboard to wake it up, press “1”+”#”, the fingerprint light goes to blue and flashing, verify the entered administrator's fingerprint or password, there will be a long "drip" sound and the blue light stopped flashing, then enter fingerprint or password users according to step 1 or 2.

V. Reset

1.Touch the keyboard to wake it up，enter “888” and press “3” to verify. The red light flashes, verify the entered administrator's fingerprint or password, the light turns green with long "drip" sound, that means successful user del and factory data reset.
2. Force to restore factory settings: Long press the Settings button 9 seconds on the handle and hold it, the green light flashes with continuous "drip" sound, after 9 seconds later, the red light flashes, release the button, the light turns green and goes off, indicating that the factory has been restored successfully.

VI. Normally Open Mode

Press the normally open button on the handle for 1 second, the light turns green, release the button with a long "drip" sound, that means it is set to normally open mode. Repeat operation can be switched to normally open mode or automatic locking mode.

1. Close the door lock in normally opening mode
Touch the keyboard to wake it up, press “#” to close the lock, or enter the recorded fingerprint or password can also close the lock, and also turn off normally open mode.

VII. Auxiliary Function

1. Press the setting button on the back handle for 1 second and verify the administrator's fingerprint or password, and you can quickly add users;
2. This product has the function of anti-peeping: when entering the password, you can add any numeral garbled code before or after the valid password, and still can open the door. But the total length of the password input cannot be longer than 12 digits
3. Press the "#" key for 3 seconds to exit the menu and enter the hibernation state;

VIII. Basic Parameters

1.Number of fingerprints: 50 fingerprints
2.Number of passwords: 100 groups
3.Power Supply: 4*AAA (1.5V) batteries.

IX. Tips

1. Please store your mechanical keys outside for emergency use
2. When the battery power of the door lock is insufficient, it can also be opened about 50 times, and the red light will flicker
When the battery of the door lock has run out of power, you can open the door through the mechanical key or by input power with power bank.