dimax

Modelo: H33

Notes Before Installation
1. Wi-Fi Only support a 2.4GHz network (802.11 b/g/n)
2.Neutral wire Required.
3.Basic electrical wiring knowledge or experience required , or please consult a professional installer.
4.OTHER Button can be used as reset button, long press to reset your dimmer switch to factory defaults. Only do this if you are sure you want to erase all your settings

1

Check your bulb situation

All incandescent bulbs are dimmable, but not all LEDs are.
Check the light bulb package to confirm

(Note: Does not support CFL bulbs)

The number of lights your Dimmer can control depends on the type of bulb and whether the Dimmer is installed in a single-switch box or a multi-switch box.

WARNING RISK OF ELECTRIC SHOCK
Incorrect installation could be dangerous or illegal. Multiple breakers may need to be energized for safe installation. If you are not a professional electrician if you are unfamiliar or uncomfortable with electrical work

2

Installation Guide

Step 1

Turn off circuit breaker

Find your Light Switch in your electrical service breaker and turn it off. Then make sure the power is off by Flipping your switch a few times.

Step 2

Find the neutral wire

In the wire bundle in the switch box, there are many white wires and you usually can't find out a neutral wire in your switch box, please contact professional electrician to help you.

3

Step 3

3 Way Switch Diagram(Single)

4

3-Way Switch Diagram(Double)

5

Switch Can Replace 3 Way or Single Pole Switch

Installation Tips:
1. The Most important to mark the Common & Traveler wires before you remove any from the old switch
2. There is no standard for wire colors, the wire colors in your house/area is assumed code by any color

6

STEP-3 Turn on circuit breaker

Turn on your switch/ Light from the circuit breaker
Press the switch a few times to make sure it works.

STEP-4 Check the indicator status

Tap MUSIC when the indicator blinks

Indicator rapidly blinks
(2 times per second)

7

Install the "Smart Life" APP

Step A. Find out "Smart Life" App in Apple or Andr- oid store. Google Play, or scan the QR code below and install it.

The free app"Smart Life" is compatible with mobile devices that support IOS8.0 above, Android 4.4 above

Step B : Enter the register interface, input the email/ address/phone number for getting the verification code to register an account. Please just login if you already have a Smart Life account.

8

Step C Add the switch to Smart Life APP

Note: This smart switch can only support 2.4G network and cannot work with 5.8G network, please confirm that your router has network in 2.4G and make sure that your phone has been connected to your Wi-Fi home network.

(1)Tap"+" Button on top right corner to add device, the tap" switch" to enter next page.

9

Default Mode(Recommend)

Indicator light rapidly blinks(2 times per second)

Step 1 Make sure the indicator blinks rapidly, if not, hold the ON/OFF button for 5 -10 seconds the reset.

Step 2. Enter the Wi-Fi password in your your home network

Step 3. Power on the device and restart

Step 4. Wait till device is connected successfully

Step 5. Device added successfully, device name modify, device name

10

AP Mode(Alternative)

Indicator light slowly blinks(1 time every 2 seconds)

Step 1. When the indicator blinks rapidly, press and hold the ON/OFF button for another 7 -10 seconds. The indicator will blink slowly (1 time every 2 seconds)

11

Step 5.

Step 6.
(Note: Please use 2.4G)

Step 7.

Step 8.

12

Step D Give a name to the switch and tap"Completed", you will find the device you've named is shown on the home screen page. Tap the device to enter the setting page.

Note: The name you give to the device will be the name for voice control on Amazon Alexa or Google Home later. Please name it properly, for example "Bedroom Switch".

13

After completing Part Two, you can control the switch with Smart Life APP on this setting page now.

14

Try timer function to verify set up schedule to turn ON/OFF dimmer switch

15

If you want to connect to Amazon Alexa, Google Home, please follow the instructions to find the guide in the app (Here are the instructions, videos and detailed steps)

If you have any questions, please check the "Help Center" in the app, maybe you can find a solution

16

FAQ

Q: After dimmer installed, failure to pair APP

A: 1. Is the position of the installed dimmer covered by Wi-Fi ? Or is it far from the router? or signal is weak? Make sure that the position where the dimmer is installed can receive the Wi-Fi signal normally.
2. Please confirm that the Wi-Fi router is 2.4GHz. (Does not support 5GHz)
3. Please confirm that the Wi-Fi router is 2.4GHz. (Device does not support N2Mz)
4. Check if the above instructions are correct One will failure to be connected, please re-pair with APP mode.

Q: Why doesn't the light remember me?

A: 1. The lamps support dimmer,choose Level N. If the lamps can't support dimmer, please choose level of N

2. Please confirm whether the lamp is dimmable.

3.When the lamp switch is turned off and on the same brightness level, some LED lights do not fully reflect the former brightness, but some are not bright. Therefore you can choose 1" level or 2" level to adjust the former brightness according your requirement.

17

FCC NOTICE:
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation. The manufacturer is not responsible for any radio or television interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

English
Español

EL USUARIO ES THE RISK OF OVERSTATING AND POSSIBLE
DAMAGE TO THE DIMMER AND PRODUCT. DO NOT INSTALL
CONTROL AND ESTABLE A MOTOR OPERATED (OPPLIANCE,
THE TRANSFORMER IS FOR LIGHTS ONLY

18